

www.coretechortho.com

coretech[®]
by vive health

OWNER'S MANUAL
830 TRI-PANEL KNEE
IMMOBILIZER
SKU: SUP2047BLK



To see all FAQs in one place, visit [coretechortho.link/rmb](https://www.coretechortho.com/link/rmb)

830 TRI-PANEL KNEE IMMOBILIZER

APPLICATION

NOTE: Assistance required.

1. Loosen and undo all straps from the D-rings so that the support can lay flat. Secure the straps onto themselves for later use.
2. Have the patient extend their leg on a flat surface, then place the support underneath their leg with the rear \ splints centered on the leg.
3. Lift the support panels over the sides of the knee, the sides should be covered and the knee cap should be exposed.



4. Loop the straps through the D-rings and secure them from bottom to top.



Tighten and adjust the straps as needed for a comfortable fit.



5. Have the patient stand up and walk around to test the fit, make any adjustments to the straps or supports if needed.



ADJUSTING THE SIDE PANELS

If the side panels are too short or too long, they can be adjusted to the proper fit. Simply detach them and reposition using the hook and loop tabs to fit the patient's leg.



SHAPING THE REAR SPLINT

If the patient has a large gap underneath their knee, the back splint can be bent to the proper angle of support.

1. Position the Tri-Panel Knee Immobilizer over the edge of a hard surface, such as a table, with one end flat and the opposite end hanging. The inside of the support should be facing out.



2. Use one hand to hold the support in place and with the opposite hand press down onto the end hanging from the edge to produce a bend. Adjust as needed.



CARE

- Remove the inner splints and hand-wash the pads with cold water and mild soap. Hang dry. Do NOT machine wash or dry. Do NOT bleach.

coretech®
by **vive health**

Distributed by

vive
health

8955 Fontana Del Sol Way
Naples, FL 34109
1-800-487-3808
www.vivehealth.com