

KNEE BRACE WITH STAYS

SUP2009BLK



Check out this how-to video at,
vhealth.link/tuw

vive
vivehealth.com

QUICK START GUIDE

NOTE:

Due to the nature of the fabric, please remove the product from packaging and let air out 6-8 hours in a well ventilated room to dissipate neoprene smell.

HOW TO PUT ON THE KNEE BRACE



For a video demonstration,
check out vhealth.link/jz9

1. In a seated position, extend your leg so that your knee is straight.

2. Position the open ring in the center of the brace directly on top of your patella and the long strap oriented at the top of the brace.



3. Wrap the top strap above your knee and the shorter strap below your knee, and secure in place with the fabric fasteners.



vive
vivehealth.com

Distributed by

vive
health

8955 Fontana Del Sol Way
Naples, FL 34109
1-800-487-3808
www.vivehealth.com

4. Stand up, then bend and straighten your knee a few times to test the fit.
5. Adjust the fit to achieve the desired degree of compression and support.



CARE INSTRUCTIONS

- Make sure to remove the four aluminum splints from the fabric pockets on the outside of the brace prior to washing the knee brace.
- Be sure to secure the velcro to the brace, as it will attach to clothing in the washing machine.
- Machine wash cold with like colors.
- Hang or air dry.
- Do not bleach.